




**INNER SUPPORT FOR FLANGE**



Name	Model	Specification (Inch)	Frequency (MHz)
INNER SUPPORT FOR FLANGE	RL078-02	7/8"	DC-880
	RL158-07	1-5/8"	
	RL318-08	3-1/8"	
	RL412-07	4-1/2"	
	RL618-07	6-1/8"	

